



TS



TF



TSBK



HS



HSBK



FRS



FRSBK

	100	125	160	200							100	125	160	200
	12mm	12mm	16mm	16mm							20x50	22x50	27x60	27x60

έδραση
support **1**

σελίδα.page.11

100	32	105x85	80x60	9	128	38	120		120	1-100-NE.R-TS	1-100-NE.R-TF	1-100-NE.R-TSBK
125	40	105x85	80x60	9	155	45	120		180	1-125-NE.R-TS	1-125-NE.R-TF	1-125-NE.R-TSBK
									180	1-125-NE.S-TS	1-125-NE.S-TF	1-125-NE.S-TSBK
160	50	135x110	105x80	11	199	55	146		300	1-160-NE.R-TS	1-160-NE.R-TF	1-160-NE.R-TSBK
									300	1-160-NE.S-TS	1-160-NE.S-TF	1-160-NE.S-TSBK
200	50	135x110	105x80	11	239	55	146		300	1-200-NE.R-TS	1-200-NE.R-TF	1-200-NE.R-TSBK
									300	1-200-NE.S-TS	1-200-NE.S-TF	1-200-NE.S-TSBK

Για κάθε διαφορετική προσαρμογή, αντικαταστήστε το –TS από τον αντίστοιχο κωδικό με πλάκα, με την σχετική περιγραφή (-HS για τρύπα -FRS για πείρο)

Παράδειγμα: 1-100-NE.R-TS με πλάκα
1-100-NE.R-HS με τρύπα
1-100-NE.R-FRS με πείρο

Για φρένο, προσθέστε την κατάληξη –BK στο τέλος του αντίστοιχου κωδικού

Παράδειγμα: 1-100-NE.R-HS με τρύπα
1-100-NE.R-HSBK με τρύπα και φρένο



For each different type of fitting, substitute –TS from the relative code with top plate, with the specific description (-HS for bolt hole -FRS for stem)

Example: 1-100-NE.R-TS with top plate
1-100-NE.R-HS with bolt hole
1-100-NE.R-FRS with stem

For brake, add –BK at the end of the relative code

Example: 1-100-NE.R-HS with bolt hole
1-100-NE.R-HSBK with bolt hole and brake